


Universal Portable Towbars

Models: 01-1215-0000, 01-1216-0000



Tronair recommends towbar inspections at least once a week.

- ❑ Check towing eye for bending, excessive wear and deformity. If any are located, remove towbar from service and contact Tronair for repair.
- ❑ Check towing eye mounting bolts. Ensure the fasteners are tight and not missing. Tighten to 25 ft-lbs or replace as required.
- ❑ Inspect the towbar tube for cracks, gouges greater than 1/16", and bends or deformities. If any are located, remove towbar from service and contact Tronair for repair.
- ❑ Check the towbar tubes to ensure they slide within each other as intended. If the tubes bind, it indicates that bending has occurred. Remove towbar from service and contact Tronair or your Tronair distributor for replacement of bent section(s).
- ❑ Inspect ball-lok pins for bending or unusual wear. Verify the factory supplied pin is used. Contact Tronair or your Tronair distributor for replacement if required. Use only Tronair specified ball-lok pins.
- ❑ Ensure the ball-lok pins are connected to the towbar via their lanyards (if applicable). Replace lanyard(s) if missing.

INS-1791